

Valid for all product groups, except for SibuGlas (SG) and ANTIGRAV
Design sheets are exclusively recommended for indoor applications

Jupiterstraße 8 - 4452 Ternberg - Austria
Tel.: +43 (0) 7256.6025.0 - E-mail: info@sibu.at - www.sibu.at


1



Ground preparation for bonding SIBU DESIGN sheets

- The ground should be dry and flat, free from loose parts, dust, dirt, grease, wax and silicone. To achieve a maximum adhesion, non-absorbent surfaces should be cleaned with alcohol (ethanol, isopropyl alcohol).
- Self-adhesive (SA) sheets are suitable for both non-absorbent and absorbent surfaces such as plasterboard, uncoated chipboard, MDF or smoothed brickwork, **whereby non-absorbent grounds are recommended.** Adhesive backed design panels (SA) are not suitable for ceiling applications. Alternative processing options are available on request.
- When applying **MultiStyle (MS)** to highly absorbent surfaces such as brickwork, plasterboard and uncoated chipboard, we recommend the use of our **additional SIBUKLE adhesive.**
- In the case of non-adhesive STRUCTURE-LINE (SL) and DECO-LINE (DM) sheets, we also recommend our dispersion adhesive SIBUKLE D22HV for use in connection with porous or highly absorbent surfaces such as brickwork, plasterboard and uncoated chipboard.
- In case of non-absorbent grounds surface tension should be at least 38 dyn (industrial info!). For application on convex or concave grounds all sheet edges must be fixed mechanically.

2



General bonding information

- Ideal processing temperatures range from + 10 °C to + 30 °C. The design sheets should be acclimatised, i.e. be brought to room temperature prior to processing (avoidance of condensation on the gluing surface and a reduction in sheet expansion due to reduced temperature differences).
- A temperature increase of 10 °C will cause our products to expand by approx. 0.7 mm over a length of 1 meter.
- **As a rule, an approx. 2-3 mm expansion joint is to be left along the sheet edge!**
- In case of high surroundings temperature or major temperature-fluctuations the expansion gap should be increased or the sheet format should be chosen smaller.
- Avoid blistering (air inclusions); use a medium-hard hand rubber roller with a width of approx. 170 mm.
- Remove the backing cover step-by-step from self-adhesive design sheet (SA), do not touch gluing surface and press the sheet onto the ground as firmly as possible. The final adhesion power will be reached at room temperature after 24 hours.
- **Patterned sheets delivered in rolled form should be kept flat for a minimum of 24 hours. Weighing down improves evenness.**
- SIBU DESIGN sheets should be processed within 18 months (PVA pre-treated products are excluded).



3




Processing with SIBUKLE D22HV (solvent-free dispersion adhesive)

- Application: SIBUKLE D 22 HV is ideally suited to the bonding of SIBU products onto absorbent, even surfaces such as wood, plywood, chipboard, plasterboard or smooth brickwork.
- **As a rule, an approx. 2-3 mm expansion joint is to be left along the sheet edge!**
- ATTENTION: SIBUKLE D 22 HV is not suited for non-absorbent grounds such as tiles, plastics, metals, glass, etc.
- Processing: Apply exclusively on the entire cleaned ground by means of fine spatula (spatula toothing is given for every product). At a surroundings temperature between 20 °C and 35 °C the adhesive should then be left to air for 20 - 50 minutes. No drying time is required for PNL and MultiStyle Fashion products, which can be bonded in a wet adhesive bed.
- The higher the surroundings temperature is the shorter is the airing time.
- Finger test: After application with the spatula the maximum airing time is reached as soon as the glue no longer sticks to the fingers!
- Storage: In the original airtight containers the adhesive can be stored up to 12 months from delivery date. Store always above freezing point.




4



PVA-Pressing

- Non adhesive design sheets from our DECO-LINE, LEATHER-LINE, STRUCTURE-LINE and ACRYLIC-LINE series (with a few exceptions) are compressible with commercial PVA adhesives. The ground must be absorbent (MDF, chipboard, etc.)
- As a result of this type of processing, standard edges of plastic, aluminium or wood can be used! The PVA adhesive prevents the usual expansion of our design sheets due to the effect of increased temperature!
- In order to be suited to PVA bonding, SIBU design sheets have to be pre-treated according to material thickness on the reverse side either by an additional production process or customer-sided grinding (using sandpaper - granulation 80).
- When pressing structured design sheets (STRUCTURE-LINE, ACRYLIC LINE and LEATHER-LINE), a medium-hard sponge rubber mat with a thickness of approx. 5 mm should be used between the pressing sheet and the patterned side of the design sheet. This provides uniform pressure distribution and prevents undesirable crushing spots caused inadvertently by particles of dirt between the pressing sheet and the design sheet. If you want to have a perfect mirror result, ask us for design sheets in 2 mm thickness.
- Should by reason of transport or stock conditions the design sheet not have a crease-free protective film, the film should be removed prior to pressing process. The pressure applied should amount to 2 kg/cm² (0.2 N/mm²), the temperature to approx. 45 °C and the pressing time to around 10 minutes. The bonding of the balancing material and the design sheet should be done in a single working process.
- During pressing onto an untreated particle board in 16 mm thickness, best results were achieved with a 1 mm polystyrene balancing sheet. SL LINEA products require a polystyrene balancing sheet with a thickness of 1.5 mm.
- Following pressing allow the sheets to cool in a stack over night (about 16 hours). Cover the stack with a 19 mm plate so that the uppermost sheet also remains flat.
- Products pre-treated with PVA should be processed within the stated period (between 3 and 6 months).

5



Column facing with non adhesive (NA) products

- When covering columns, the bending radius of the respective SIBU product must be accounted for (please see the product characteristics in the OVERVIEW catalogue).
- We recommend double-sided, adhesive tape in order to fix both ends as a help during application.
- An expansion joint of 2-3 mm is also to be left when covering columns.
- It is essential that a mechanical fastening such as a floor transition profile is used as edging.
- During column applications involving MultiStyle products, on absorbent surfaces we recommend the additional use of SIBUKLE D22HV.


6



Surface protection

- A protective film protects our surfaces against damages. This protective film should be removed only after the application of our design sheets.
- Following the removal of the protective film, no adhesive tape, e.g. Scotch, Sellotape should be allowed to stick to the unprotected, decorative surface.


7



Cutting

- SIBU Deco-Line sheets with less than 2 mm thickness can be easily cut with a wallpaper knife. Simply notch the surface and break about the edge. For all other product lines and for DECO-LINE sheets up to 3 mm thickness the cutting pressure has to be increased. After cutting and breaking our self adhesive (SA) design sheets as well as 3D PUNCH-LINE designs (NA + SA) the foil on the back side has to be cut separately. Always use well sharp knives. For mechanical cutting, we recommend the use of paper or veneer cutting machines.


8



Punching

- Band steel cutting is recommended for design sheets in thickness from 1 up to 1.5 mm.


9



Drilling

- All SIBU design sheets can be drilled from the decor side.


10



Sawing

- For material up to 1 mm thickness: HW 280x3.2 / 2.2x30 Z60 / 12.46-18,08 WZ
- For more than 1 mm thickness: HW 250x3.2 / 2.2x30 Z40 / 19.63 WZ, HW 250x3.2 / 2.2x30 Z40 / 19.63 FZ/TZ. Rotation speed 6000 rpm – progressive feed up to 25 m/min
For LEATHER-LINE: HW 255x2.8 / 2.0x30 Z80 / 10.01 FZ WZ. Rotation speed 6000 rpm – progressive feed up to 10 m/min
- With LEATHER-LINE the best result is achieved with MDF increment (4 mm) below and on top, low progressive feed and high rotation.


11



Milling

- For material up to 2 mm thickness: cutter with 3 mm diameter, rotation speed from 12000 up to 24000 rpm, progressive feed up to 20 m/min. Decor side on top: single-edged cutter - left turn,
- Decor side below: double-edged cutter - right turn. For material with more than 2 mm thickness reduce progressive feed and use a cutter with bigger diameter (6 mm).


12



Laser cutting

- SIBU design sheets can be processed with standard lasers. The cutting speed conforms to the watt power of the laser.
- To find out if the chosen product is suitable, check the technical table in our Overview or go to www.sibu.at


13



Printing

- Use screen and digital printing on smooth surfaces. Digital printing is possible on structured surfaces. Multistyle products are digital printable (for product suitability please see the OVERVIEW catalogue). We offer original samples for tests. Info sheets on demand.


14



Profile handling

- The profiles must be acclimatised, which means that they have to be brought up to room temperature prior to use.
- Cutting must always take place on the upper surface. The profiles must be sawn for a mitred cut and precise edge angle quality.
- The positioning of the profiles must be selected in such a way that the material expansion of the covered sheet can take place behind the profile nose (2-3mm).
- The exact positioning of the sections on the ground is necessary, as previously glued profiles cannot be stuck down again.

15



Cleaning/Care

- DECO-LINE, STRUCTURE-LINE, ACRYLIC-LINE, PUNCH-LINE, PUNCH-LINE 3D: in case of light dirt by means of soft cleaning cloth (it should be free of dust and free of dirt).
- In case of thick dirt by means of standard plastic or window cleaner (spray cleaners not onto the material surface, but sparingly onto the cleaning cloth).
- Do not use abrasive cleaners, solvent cleaners or pure alcohol!
- LEATHER-LINE: Clean leather surfaces by means of standard liquid soap and then remove the soap with a humid cloth.
- Imitation fur surfaces: In case of light dirt clean LL Marabu, LL Reggae with a vacuum cleaner, in case of strong dirt clean with a humid cloth.
- We recommend that printed surfaces are only cleaned with slightly soapy water. No abrasive, glass cleaning or similar agents may be used. Rinse with clean water. Cleaning/care may vary in accordance with the printing colour manufacturer.
- POLISHING KIT for ACRYLIC-LINE. Marks from use or scratches on the acrylic surfaces can be repeatedly removed using the polishing kit. Polishing simultaneously protects the surface. The kit contains polishing paste, a sponge and a polishing cloth.



16



Disposal

- The keeping of healthy environment has high priority for us! We check all raw materials used for their environmental compatibility.
- Because not everyone has its own plastic disposal container, we pay special attention in development of new products to use only high-quality materials: materials, which may be disposed safely with the domestic waste. By request we are pleased to provide LGA certificates for all SIBU design sheets.


17



Storage instructions

- SIBU design sheets must always be kept in indoor stock, no storage outside!** Following instructions are to be considered:
- Design sheets to be stored flat, rolled packed design sheets should be unpacked and laid out flat and - if necessary - subjected to additional weight to improve flatness (Use carton underlay and weigh down the entire sheet in order to prevent damage.)
 - Store the uppermost plate in the pile with decor side down.
 - Protect SIBU products from UV rays.
 - Do not expose SIBU products to moisture or humidity.
 - Protect material from dirt, dust and mechanical damages.
 - A permanent storage of more than 3 months in temperature less than 0 °C or more than + 30 °C may impact the quality of our design sheets and should be avoided.
 - SIBUKLE D 22 HV should not be long-time stored below + 5 °C and must be protected from frost during transportation.


18



Transport instructions

- In general, for the transport of SIBU products pay attention to protect them from dirt, UV radiation, moisture and mechanical damages.
- Use stable, flat pallets with carton bedding, the pallet should be longer than the design sheets.
 - Place the uppermost design sheet on the pallet with the decoration side face down. This uppermost design sheet should be protected in addition by a carton and a board (e.g., chipboard, HDF...). The SIBU sheets should be protected against slippage.
 - The edges and sides must also be safeguarded (edge protection, PE film, ...)
 - Temperatures may not fall below -35 °C, or exceed +50 °C.
 - Structured sheets to be transported on pallets with the patterns running in same direction.
 - Basically, the transport of SIBU design sheets in rolled condition is possible. To find out if the chosen product is suitable, check the technical table in our Overview or go to www.sibu.at

19



Further information about the processing of our products can be found in the SIBU DESIGN Processing Movies at www.sibu.at.

This information leaflet has been prepared to the best of our knowledge and with special care. Its content derives from practical experience and in-company testing and corresponds with our current know-how. The leaflet should serve as information and does not contain any guarantees with regard to product characteristics or suitability for certain applications. Not recommended for use near open fires or strong heat sources. Never apply packaging adhesive tape right to our decorative surface. No responsibility is accepted for printing and standard errors and mistakes.